

PRESMA Binoculars

CAUTION! Viewing the sun can cause permanent eye damage. Do not view the sun with this binocular or even with the naked eye.

Operation Manual

HOW TO USE YOUR BINOCULAR:



IPD ADJUSTMENT

• Set the interpupillary distance by grasping the body and bending it until you can see on circle of view. The setting for your eyes will be indicated on the IPD Scale. (Note the scale setting for later use.)



FOCUSING

- Close your left eye and sight an object with your right eye. Focus the binocular by rotating the center focus wheel until the image is sharp and clear.
- Open your right eye and close your left eye. Rotate the right eyepiece until the object sighted is sharp and clear (Note the setting of the diopter scale for later use.)
- Both sides (eyes) are now in focus and you will need to use only the center focus wheel to focus on the other objects.



RUBBER FOLD-DOWN EYE CUPS

- Fold down for use with eyeglasses and fold up for use without eyeglasses. They provide comfort and promote view ease.

HOW TO CARE FOR YOUR BINOCULAR

- Keep the lens covers (that come with your binocular, except compact type) on the lenses when binocular is not in use.

- When wiping the lenses, use the lens cloth that come with the binocular or a soft cloth.
- To remove any remaining dirt or smudges, add one or two drops of isopropyl alcohol to the cloth.
- Store your binocular in a moisture-free area.

MAINTENANCE - Never attempt to clean your binocular internally or try to take it apart.

CAUTION! Viewing the sun can cause permanent eye damage. Do not view the sun with this binocular or even with the naked eye.

LIFETIME LIMITED WARRANTY

Congratulation on your new purchase of the Presma series product. Your product is warranty to be free of defects in material and workmanship for lifetime of the original ownership as long it is purchased and used in the United States. This warranty covers the original purchaser of the product and it is non-transferable.

In the event of the defect within 30 days the consumer must return the defective unite to the PRESMA dealer/distributor (the place of purchase) at his/her own expense.

Beyond 30 days, PRESMA products should be sent to the following address for warranty repairs. Products must be packed carefully and sturdily to prevent damage in transit and returned freight prepaid to:

PRESMA INC Repair Department
9002 Hyssop Drive, Rancho Cucamonga, CA 91730

This warranty does not cover damages results from normal wear and tear of failure with routine maintenance. This warranty does not cover the accessories. In the event of a claim under this warranty, we will, under our discretion repair or replace the product provided that the inspection indicated a defect in material or workmanship. PRESMA reserves the rights to replace a product which is no longer available with a product of comparable model or value. You will be responsible for handling change with or repair charges if the product is not covered within our warranty guidelines. This is a limited warranty and it does not cover damages caused by misuse, improper handling, installation, or maintenance provided by third party other than an authorized PRESMA technician.

For warranty service, Please visit our website www.presmainc.com. Or, call 1-909-367-2280 or email info@sniper-corp.com for Return A uthorization number (RMA#) before returning the product for repair or service. You must provide a valid proof of purchase, receipt, or bill of dale. You are responsible for the shipping charge to or delivery of product to our service center for any warranty work. PRESMA will not be held recommend using reputable shipping company that offers shipping insurance.

Copyright reserved. Trademark is reserved and belong to Presma Inc. www.presmainc.com. info@sniper-corp.com welcome your suggestions and comments.